



Package Contents:



- (1) CMPTRI – Flexible Mini 7.5" Tripod
- (1) MG002 – Mobile Grip 2 Universal Smartphone Holder
- (1) AP142017MM – 1/4"-20 Camera Pattern to 17mm Ball Adapter
- (1) SP-SB-RING – Swivel Tightening Ring
- (1) CAM-POUCH – Carrying Bag

Device Compatibility:

Small digital cameras with the standard 1/4"-20 camera pattern, including the Sony Action Cam, Sony POV HD Flash Memory Camcorder, Contour ROAM2, JVC ADIXXION, Samsung NX2000 and Samsung NX300, Olympus OM-D E-M1, E-M5, E-M10, Fujifilm X100T, Nikon Coolpix S9700, Panasonic Lumix DMC-FZ70, Canon PowerShot S120, SX50, PowerShot G16 X Mk II. Compatible with all smartphones.



Using With Digital Camera:

- 1 Attach camera by screwing it onto the 1/4"-20 mounting bolt.
- 2 Loosen the adjustment knob to change position and retighten to set.
- 3 Release the 1/4"-20 mount by unscrewing lateral screw and pressing on release tab.






Using the Mobile Grip 2 Universal Holder:

- 1 Screw end of Mobile Grip 2 Universal Holder directly onto the 1/4"-20 mounting bolt.
- 2 Insert device and adjust as needed.



Using the 17mm Ball Adapter with the Mobile Grip 2 Universal Holder:

- 1 Screw 17mm Ball Adapter onto the 1/4"-20 mounting bolt.
- 2 Place tightening ring over the adapter mount ball and snap Mobile Grip 2 Universal Holder onto the adapter mount.
- 3 Insert device and tighten ring to set position.



Safety Precautions

Arkon is not responsible for any damages caused to your device or yourself due to the installation or use of the mount.



The Mobile Mounting Specialists™

Consumer Hotline:
 USA (800) 841-0884
 INT'L (626) 254-9005
 Monday - Friday 9 am - 5 pm, PST

www.arkon.com
 Arcadia, CA 91006 USA
 Designed in USA | Made in China
 © Copyright 2015 Arkon Resources, Inc.